

3075-GS STEREO GEM STAND MICROSCOPE

The Gemological Professionals Microscope

CRISP,
HIGH
RESOLUTION
IMAGES

BRIGHTFIELD/
DARKFIELD
ILLUMINATION

TWO
DIFFERENT
REFLECTED
LIGHT
SOURCES
FOR VIEWING
FACETS
AND
SURFACE
GRAINING



Delivering quality through vision

3075-GS ZOOM STEREO GEM STAND MICROSCOPE

ACCU-SCOPE's Gemological Zoom Stereo Microscope offers crisp high resolution images, brightfield/darkfield illumination, and two different reflected light sources for viewing facets and surface graining.

With an ergonomic design, 325° rotatable base, 10x – 67.5x zoom range and an optional pin point, variable LED light guide, ACCU-SCOPE provides a best in class solution for today's discriminating jewelry retailer.

SPECIFICATIONS

Optical System	10x - 67.5x zoom range; 0.67x - 4.5x zoom objective; 100mm working distance
Eyepieces	WF15x/16mm focusable eyepieces with roll-down eyeguards; interpupillary distance adjustment 54-76mm
Brightfield & Darkfield	Featuring a super-bright variable halogen illuminator, sliding baffle and an iris diaphragm
Illumination	Halogen brightfield/darkfield illuminator; 7 watt fluorescent light for reflected illumination that simulates North Facing daylight for accurate color grading and an optional pin point, variable LED light on a flexible gooseneck
Stand	Base rotates 0°-325° and tilts 0°-38°
Focusing System	Coarse focus controls with 110mm focusing range
Accessories	Steel wire stone holder allows for multi-angled viewing of various sized gems
Miscellaneous	Universal power supply -- 110v - 240v
Warranty	5 year limited warranty for parts and labor, 3 years on electronic components

Design, features and specifications are subject to change without notice.

ISO 9001

Design and production adheres to ISO 9001 international quality standard.

ISO 14001

Design and production meets the Requirements of international standard ISO 14001 for environmental management.



The included wire Stone holder pivots 360° for easier changing of gemstones and rotates 360° for viewing at any angle.



The tilting base swivels 325° for quick and easy multi-angled viewing



New York
Microscope
Company

Microscope Experts since 1979

100 Lauman Lane, Suite A, Hicksville, NY 11801
Tel: (877) 877-7274 | Fax: (516) 801-2046
Email: Info@nyscopes.com
www.microscopeinternational.com